


# HERZ Pressfit Connection Male thread

Data sheet for C 6251 0x, Issue 0523

## Dimensions



Order Nr.	DN	A [mm]	B [mm]	C [mm]	D [mm]	E [AG]	F [mm]
C <b>6251</b> 01	15	42	24	37	15	1/2"	27
C <b>6251</b> 02	20	44	24	37	22	3/4"	32
C <b>6251</b> 03	25	46	26	37	28	1"	39
C <b>6251</b> 04	32	47	26	38	35	11⁄4"	47
C <b>6251</b> 05	40	64	41	55	42	1½"	55
C <b>6251</b> 06	50	68	43	59	54	2"	68

# Material and construction

Body: red brass (gunmetal) acc. to EN 1982, CC 449K

Seals: EPDM

Pressfit ends: Conex >B< Press
Threaded connections: acc. to ISO 228 parallel

# Operating data

Max. operating pressure: 16 bar Min. operating temperature: -10°C Max. operating temperature: 110°C



#### Pressfit connection

Conex >B< Press connections benefit from patented 'leak before press' O-ring technology which indicates if a joint has not been pressed. The O-ring contains two in-built water pathways that allow water to pass through and create a noticeable leak when the system is tested at low pressure (0.1 to 6.0 bar). Any un-pressed joints can easily be identified during the test phase and pressed, saving valuable time and money. There is no need to drain down as the pressing operation can be carried out while the water is still in the system.

>B< Press fittings are installed using a press tool with a compatible press jaw. Jaws are sized to match the fitting required. When force is exerted through the press tool the jaw closes to make a permanent joint.

The >B< Press design has the advantage of a 3-point press profile; comprising of two mechanical presses on either side of the bead, and one press on the O-ring bead. The EPDM O-ring compresses to form a permanent leakproof joint.

>B< Press red brass fittings maintain earth continuity without the need for additional continuity straps.

>B< Press red brass fittings can be used on hard, half-hard and soft copper tube to EN 1057, Stainless Steel tubes to EN10312 and Carbon Steel tubes to EN10305.


Please note that Carbon Steel is susceptible to Galvanic Corrosion due to the coating and the normal precautions need to be applied.

Red Brass on Carbon Steel is also more susceptible to Bi-Metallic corrosion.

It is recommended that all pipework jointing connections are made un-pressed within a contained section to avoid disturbing any valve connection joints during construction. Once a section is completed, all connection joints should be pressed together in one operation.

#### Assembly procedure

Ensure both O rings are fitted to the Adaptor and no debris or sharp edges are visible.



Screw the adapter into the valve so that the O ring compresses against the face of the valve and tighten to a torque of at least 20Nm. To ensure a stable leak tight connection Herz recommend using Loctite 577 thread sealant and SF7649 activator as per the manufacturer's instructions avoiding contact with the O ring. Failure to use Loctite to seal the joint will invalidate the warranty.

All specifications and statements within this document are according to information available at the time of printing and meant for informational purpose only. Herz Armaturen reserves the right to modify and change products as well as its technical specifications and/or it functioning according to technological progress and requirements. It is understood that all images of Herz products are symbolic representations and therefore may visually differ from the actual product. Colours may differ due to printing technology used. In case of any further questions don't hesitate to contact your closest HERZ Branch-office.



# >B< Press fittings Installation instructions

# **☑** Compatible Press Tools

12 to 35mm Compact machines					
Manufacturer	Press machine Press jaws		Jaw profile		
Rothenberger	Romax compact	Rothenberger - Compact	SV		
Rottieriberger	Romax compact TT	Rothenberger - Compact	SV		
Rems	Mini Press ACC	Rems - Mini	V		
IZI I -	MAP1/MAP2L/MAP215	Klauke - SBM	KSP4		
Klauke	MAP219/MAP2L19	Klauke - SBMX	KSP4		
Novopress	ACO102/ACO103	NovoPress - V-PB1	V		
Milwaukee	M12	Milwaukee - J12	V		
Hilti	NPR 019 IE-A22	Hilti - NPR PM V	V		
Ridgid	RP 200/210/240/241	Ridgid - Compact Series	V		
Conel	PM 1	Conel - V-PB1	V		
Viega	Pico	Viega Pico	PT2		

12 to 54mm Standard 32kN machines					
Manufacturer	Press machine	Press jaws	Jaw profile		
Rothenberger	Romax 3000/4000	Rothenberger - Standard*	SV		
Rems	Power-Press/ Akku-Press	Rems - Standard*	V		
Novopress	ECO/ACO202/203	NovoPress - V-PB2*	V**		
Conel	PM 2	Conel - V-PB2*	V		
Klauke	UAP2/UAP3L/UAP332	Klauke - Standard SB**	KSP4		
Ridgid	RP 320/330/340	Ridgid - Standard Series	V		
Hilti	NPR 019 IE-A22	Hilti - NPR PS V*	V		
Milwaukee	M18	Milwaukee - J18*	V**		
Viega	Pressgun 5/6	Viega Standard*	PT2		

<sup>\*</sup> Press Jaw only - not press slings, collars, chains or rings


For inter tool compatibility please refer back to the manufacturer

<sup>\*\*</sup> Novopress & Milwaukee jaws with the parking only



# **☑** Space required for the pressing process

The following minimum clearances are required from structural components to allow operation of tool for press fitting.




<b>4</b> ·-·	
Y2	TOTAL D
Y1 -	O P
	x

Space required for the pressing process between fittings						
External tube	External tube X Y					
Size mm	mm	mm				
15	26	53				
22	26	54				
28	33	69				
35	33	73				
42	75	115				
54	85	120				

Space required for the pressing process between fittings								
External tube	External tube X Y1 Y2							
Size mm	mm	mm	mm					
15	31	45	73					
22	31	45	76					
28	38	55	80					
35	38	55	85					
42	75	75	115					
54	85	85	140					

# ☑ Insertion depth and minimum distances between pressings



Size	External – Ø pressing bead	Min distance	Min tube length	Insertion depth
Size mm	D - mm	A - mm	L - mm	E - mm
15	22.6	10	54	22
22	31	20	66	23
28	37	20	68	24
35	44	25	77	26
42	53.4	30	102	36
54	65.4	35	115	40

Due to reforming of the tube profile when pressed, it is advised that a minimum distance is allowed between each fitting.



# Minimum distance for press fittings from an existing brazed joint

To ensure proper sealing of both the brazed and pressed joints, the following minimum distances must be maintained between the joints.

Minimum distance from a brazed joint			
Tube size	mm		
15	5		
22	5		
28	5		
35	10		
42	15		
54	20		

## Minimum brazing distance to an existing pressed fitting

Caution: Brazing or soldering near to >B< Press joints should be avoided as this may cause the seal to degrade due to heat transfer. The table below states the minimum distance away from the press joint which is acceptable to braze. If this distance cannot be maintained then adequate precautions must be taken such as fabricating the brazed section prior to assembly with the press fittings, wrapping in a wet rag or applying a hot block, to prevent heat transfer to the press fitting during brazing.

Minimum distance brazing				
Tube size mm				
15	450			
22	600			
28	700			
35	900			
42	1200			
54	1500			

## Minimum brazing distance to an existing pressed fitting

>B< Press fittings can be used on hard, half-hard and soft copper tube to EN 1057 with the wall thicknesses stated below.

	Tube wall thickness (mm)						
Tube O/D	Copper - R220		Copper - R250		Copper - R290		
15	1.0	_	0.7	1.0	1.0	_	
22	1.0	1.2	0.9	1.1	1.0	1.5	
28	_	_	0.9	1.2	1.0	1.5	
35	_	_	1.2	-	1.0	1.5	
42	_	_	1.2	_	1.0	1.5	
54	_	_	1.2	_	1.2	2.0	

>B< Press red brass fittings can also be used to connect stainless steel tube in accordance with EN 10312 parts 1 and 2 and Carbon Steel tubes to EN10305.



# **▽** >B< Press installation process




- Use a rotary tube cutter
- Ensure that the tube is cut square
- Check that the tube has retained its shape and is damage free



- Deburr the tube both internally and externally.
- Where possible angle the tube downwards to prevent filings entering the tube.
- Make sure the internal and external surfaces of the tube ends are smooth and free from burrs or sharp edges.

Caution: Please ensure that the tube surface is free from any deep scores or scratches



- Check the fitting is the correct size for the tube.
- Check the O-rings are present and correctly seated.
- Additional >B< Press lubricant (silicon oil) may be used to aid tube insertion.





- The tube must be fully inserted into the fitting until it reaches the tube stop.
- To reduce the risk of dislodging the O-ring, rotate the tube (if possible) while slipping it into the fitting.
- Mark the insertion depth on the tube.
- Prior to pressing ensure the tube has not moved out from the fitting socket.



- Ensure pipework is correctly aligned prior to pressing.
- Ensure the correct size jaw is inserted into the tool.
- The jaws must be placed squarely on the fitting, locating the groove on the bead.
- The bead on the fitting should fit centrally in the groove of the jaw.
- Depress and hold the start button on the press tool to complete the pressing cycle.
- Pressing is complete when the jaws are fully closed.
- Complete the press cycle once only do not re-press.



- Mark the completed joint after pressing.
- This enables joints to be inspected easily before testing.